



# INSTALLATION INSTRUCTIONS

**PART No.**

**FB33007F**

**Jeep® JK Wrangler  
Aluminum Inner Fenders**

**FB33007F –  
Black**



**REQUIRED**



**REQUIRED TOOLS**

Drill

**FRONT INNER FENDERS:**

- 10mm Wrench
- 3mm Allen Wrench
- 1/4" Drill Bit

**KIT CONTAINS**

**FRONT INNER FENDERS:**

- M6 Button Screw
- M6 Hex Flange Nut
- M6 Flat Washer
- Nutsert Tab

**QTY**

- 10
- 2
- 10
- 2

33007F01



# INSTALLATION INSTRUCTIONS

**PART No.**

**FB33007F**

**Jeep® JK Wrangler  
Aluminum Inner Fenders**

## FRONT INNER FENDERS:

**1) REMOVE YOUR FRONT OEM INNER FENDER/LINER**

Use a 10mm socket and flat head screwdriver to remove the bolts and clips from the inner fender liner. Remove the fender liner.

**2) INSTALL YOUR FRONT INNER FENDER SUPPORT ARMS**

Passenger side – install the nutsert tab on the back side of the inner fender and facing the rear of the Jeep. Do not tighten at this time

Driver side – install the nutsert tab on the back side of the inner fender and facing the front of the Jeep. Do not tighten at this time.

**3) INSTALL YOUR FRONT INNER FENDERS**

Place the inner fenders inside the fender well. Using the supplied hardware, secure the inner fender to the Jeep using the OEM fastener locations. Install all screws loosely to allow adjustments. It may take a little pressure to get these to line up with the OE holes.

On the forward most holes, you will need to drill a ¼" hole using the inner fender as your template. Install screw and washer and tighten the nut.

Working from the front of the vehicle to the rear, tighten all bolts with a 3mm Allen wrench. When the rearmost screw is tightened, it will turn the nutsert tab against your Jeep and lock it into place.

**4) ENJOY YOUR FISHBONE OFFROAD INNER FENDERS!**