



REQUIRED TOOLS

- 3mm Allen
- 5mm Allen
- M8 Nutsert Tool

KIT CONTAINS

Rear Inner Fender Set (Driver/Passenger)

QTY

- | | |
|--|---|
| Rear Inner Fender Set (Driver/Passenger) | 1 |
| M8 Washer | 6 |
| M6 Washer | 4 |
| M8 Nutsert | 2 |
| M8 Button Head Bolt | 6 |
| M6 Button Head Bolt | 4 |
| M6 Serrated Nut | 4 |

1) PREPARE YOUR VEHICLE

Remove your vehicle's existing inner fenders. Please visit Fishbone Offroad on YouTube for instructions on how to remove your OEM parts.



Inside the wheel well, at the shown hole, with an M8 Nutsert tool, install one of the included nutserts into the vehicle.



2) INSTALL YOUR FRONT FENDERS

Note: The mesh and accent plates can be removed with a 3mm Allen key to be painted separately.

The fenders are driver and passenger side specific and can be identified by our logo pointing forward on each side.



Slide your front inner fenders into the well and align the holes behind the body and into the nutsert.



With a 3mm allen and two of the included M6 bolts, washers, and serrated nuts, secure the bottom of the fender.

With a 5mm Allen and 3 of the included M8 bolts and washers, secure the top of the fender.



Repeat on the opposite side.

- 3) **ENJOY YOUR NEW FISHBONE OFFROAD ALUMINUM INNER FENDERS!**